







# BikeYoke Grippy




SCHNITT A-A



maximum padding mark



L(ef) and R(ight) marking on inside of rubber bolt cover



SCHNITT B-B

Your BikeYoke Grippy has an eccentric rubber body, which allows to adjust the padding for your palm. The small dent on the bolt cover marks the section of the thickest padding. Adjust the grip for your preferred setting before tightening. We recommend the thickest section for the palm area.

To install properly, make sure to clean and degrease the grip area on your handlebar first. Push the grip all the way onto the handlebar. Use as little torque as possible and only as much torque as necessary on the M3 bolt to securely mount the grip to your handlebar. It should not twist too easily and not come off your handlebar. Do not exceed 4Nm!  
Make sure your handlebar's specifications allow the required torque!

